



VIMAL SALES CORPORATION

Textile Machinery & Spares



AUTOCONER SPARES

Spares For High Speed Winding Machine


Schlafhorst Autoconer 138 / 238 / 338

Schlafhorst Autoconer AC5 & X5

Schlafhorst Murata Model 7-II / 7-V / 21C

Star Volkmann TFO

Savio Autoconer Model Espero / Espero L / Orion



Schlafhorst Autoconer 238



20203-45
WASHER



20235-44
FILTER SCREEN



40T GEAR & SHAFT
CONVEYOR TUBE ASSEMBLY



27050-04
MAGAZINE CARRIER



27050-09
MAGAZINE HALF



27050-13
MAGAZINE HALF



30107-02
CPL SWITCH HOUSING



30107-03
SWITCHING HOOD




30107-12
COVER



30120-12
PISTON



30120-901
CRADLE SHOCK ABSORBER




30380-15
DEFLECTION PLATE



30380-17
DEFLECTION PLATE



31601-03
GUIDE BAR (UPPER)




31601-03
GUIDE BAR (LOWER)



32501-31
SWIVEL BOLT



32501-33
PIVOTING SLEEVE



32501-42
CAM PIECE



32510-34
OPENER ARM



33005-34
TOOTHED SEGMENT



33001-14
PILOT MOTOR SHAFT



33001-14
PILOT MOTOR WORM



33001-14
PILOT MOTOR GEAR



33010-13
CAM (FU 2.1)



Schlafhorst Autoconer 238



33012-66
CAM FOLLOWER (FU 2)



33015-13
SUCTION TUBE




33020-09
COMB STRIP (0.3 & 0.5)



33045-09
SCISSORS HOUSING



33045-14
SCISSORS SHAFT



33045-16
COVER



33045-19
SCISSORS BLADE
(CARBIDE TIPS & HSS)



33045-20
SCISSORS BLADE
(CARBIDE TIPS & HSS)



34101-03
CYLINDER



34101-07
FASTING PIECE



34101-08
GUIDE BUSH




34101-14
BEARING SHAFT



34101-17
BRAKE BUSH



34101-37
CPL BRAKE RING



34101-68
HOLDING RING (ALL SIZE)



34101-77
HOLDING RING (PU)



34201-10
BEARING (51107X)



34201-17
CPL ADOPTER (LH)



35101-21
LATCH



35101-81
STATIONARY SHEAR BLADE
(CARBIDE TIPS & HSS)



35101-84
PIVOTING SHEAR BLADE
(CARBIDE TIPS & HSS)



35101-96
TOOTHED SEGMENT



35101-113
TOOTHED SEGMENT



35101-208
LEVER


Schlafhorst Autoconer 238




35101-211
CONTROL BOLT



35201-40
BOBBIN PEG



35301-12
IC MODULE (DRIVE)




35301-104
TRANSFER ROD



35301-133
GUIDE WIRE



37201-10
CONTROL LEVER




146 MODEL
SWIVEL LID




37701-20
SPACER RING



37701-20
LID BEARING



37701-67
SWIVEL LID



37701-75
CONTROL LEVER



40101-33
TENSION DISC



40101-55
TOOTHED WHEEL



40105-10
HOLLOW SHAFT



40105-19
TENSION DISC



40105-66
GUIDE PLATE



40160-05
ACTUATING LEVER



40160-44
STATIONERY SHEAR BLADE
(CARBIDE TIPS & HSS)



40160-50
PIVOTING SHEAR BLADE
(CARBIDE TIPS & HSS)



41001-03
SUPPORT ANGLE



41001-34
ACTUATING FORK



41001-41
DOUBLE LEVER



41501-102
CUTTING KNIFE




42001-15
DRIVE SHAFT



Schlafhorst Autoconer 238



42001-19
COUPLING GEAR




42001-37
TOOTHED LEVER



42001-47
GUIDE PLATE




42001-97
WAX SHAFT



42001-104
WAX CARRIER



42001-107
YARN TRAP



42001-902
CPL WAXER SOCKET




42001-903
CPL LIFTING PLUNGER



42030-09
TOOTHED WHEEL



42030-14
BEARING SHAFT



42501-46
NOZZLE (BIG)



42501-37
NOZZLE (SMALL)



42035-08
TOOTHED SEGMENT



56801-70
TOOTHED SEGMENT



56801-98
PINION



56801-170
BALL SOCKET



56801-202
AIR DUCT




56801-210
CPL SISSORS PLATE




56801-225
SCISSORS BLADE
(CARBIDE TIPS & HSS)



56801-230
SCISSORS BLADE
(CARBIDE TIPS & HSS)



56801-310
COVER (13 MM & 16 MM)



56801-357
DISTRIBUTOR



56801-433
COUPLING HALF



61001-09
NYLON GEAR 19 T

Schlafhorst Autoconer 238



CONVEYOR GEAR



61001-26
SHAFT



61001-31
CPL ROLLER




63020-03
LEVER WITH MAGNET



65101-04/05
SHAFT



65101-35
COVER



75203-04
BEL SHIFTER (BRACKET)



80591-17
BOBBIN CARRIER
(CADDY BASE)



80591-30
BOBBIN CARRIER
(18-21 & 20-30)



80591-30
BOBBIN CARRIER
(22-25 & 24-28)



81260
SUPPORTING DISC




81260-146
ROUND BRUSH



81260-451
SUPPORTING RING




81560-20
CENTERING




85035-44
SCISSOR BLADE
(CARBIDE TIPS & HSS)



85050-116
TOOTHED LOCK WASHER




85050-117
TOOTHED LOCK WASHER




85050-125
TOOTHED LOCK WASHER



85530-18
PINION SHAFT




85530-140
CAM



85530-152
CAM



99910-46
PULLER DEVICE



99910-65
STRIPPING POT



F 208897
CAM ROLLER BEARING



Schlafhorst Autoconer 338



20230-77
CPL CYLINDER



23230-105
FILTER SCREEN




27070-02
CONE MAGAZINE




27251-62
BELT SHIFTNER



27236-13
MOUNTING WHEEL




30101-27
MODULE



30105-06
COVER



30107-04
SLIDER (BLUE & GREY)



30120/6
MAGNETIC COIL



30110-05
CLAMPING LEVER




30115-11
TOOTHED SEGMENT



30120-11
COVER



30120-14
UNIVERSAL JOINT




30120-22
CEILING RING



30125-05
CLAMPING LEVER



30125-07
STOP CAM




30125-22
STOP BRACKET



30125-31
CLAMPING LEVER



30125-35
STOP LEVER



30125-38
SHAFT



30130-06
COMPENSATING LEVER



30130-11
SPRING BRACKET




30130-28
SCALE



30301-04
MOTOR HOUSING

Schlafhorst Autoconer 338



30301-18
LOCKING RING



31320-09
LEVER



32510-22
OPENER ARM



32510-42
PACKAGE CRADLE



32510-45
CRADLE ARM BUSH (Modified)



32530-01
CPN ADAPTOR (RH)



32530-03
CYLINDER



32530-08
GUIDE BUSH




32530-14
BEARING SHAFT



32530-17
BRAKE BUSH




32530-18
FASTENING PIECE (MODIFIED)



32530-20
BRAKE LINING (TEFLON)



32530-36
BRAKE RING (CNC)




32530-60
HOLDING RING (3.30)



32530-70
HOLDING RING (5.57 & 4.20)



32530-70
HOLDING RING (PU)




32530-36
CAP



32535-18
BEARING




33001-60
CPL GEARBOX ASSEMBLY
(MODIFIED DESIGN)



33001-60
CPL GEARBOX (MODIFIED DESIGN)



33001-61
GEARBOX COVER (OLD DESIGN)



33001-62
TOOTHED WHEEL (Z 80 X 12)




33001-64
TOOTHED WHEEL (Z 86 X 12)



33001
TOOTHED WHEEL (STEEL)
Z 80 X 12 & Z 86 X 12



Schlafhorst Autoconer 338



33001-65
GEARBOX COVER PLATE
(OLD DESIGN)



33001-68
SHAFT



33001-69
TOOTHED WHEEL (Z - 22)



33001-88
VALVE




33010-06
CAM SHAFT



33010-8 & 11
TOOTHED WHEEL WITH CAM



33010-09
MAGNET HOLDER



33010-12
CAM



33010-13
SWITCH CAM



33010-15
SPACER WASHER



33010-18
CAM FOLLOWER



33010-35
TOOTHED SEGMENT



33010-43
TOOTHED SEGMENT



33020-04
SUCTION TUBE




33020-06
CLIP



33020-07
CLAMPING PIECE



33045-15
SUCTION CONNECTION



33045-05
HOUSING




33045-08
BOLT




33045-10
LEVER




33020-09
SUCTION NOZZLE



33045-16
SNAP LOCK



33045-36
PULL ROD



33045-38 / 39
SENSOR BRACKET & GASKET

Schlafhorst Autoconer 338



33050-11
SUCTION PIPE SHUTTER



33050-22
PINION



33050-35
SUCTION DUCT




36001-62
TOOTHED WHEEL (NEW DESIGN)



36001-62
TOOTHED WHEEL (FOR STEP MOTOR)



36001-74
TENSION DISC




36001-74
WORM FOR TENSION DISC




36001-81
TOOTHED WHEEL (Z-31 NEW DESIGN)




36001-81
TOOTHED WHEEL Z 31
(OLD DESIGN)



36001-105
ACTUATING LEVER




36001-165
RUBBER SLEEVE



36001-122
INTERMEDIATE PIECE



36010-141
TENSION DISC



36010-153
BLOWER NOZZLE



36060-32
SWIVEL LEVER



36060-78
ACTUATING CAM



36010-18
YARN TRAP




36010-52
LEVER



36301-64
DRIVE SHAFT



36301-66
NOTCHED DISC




36301-68
LIFTER ARM



36301-70
LIFTING PLUNGER



DRUM PULLER



36301-144
WAS SHAFT



Schlafhorst Autoconer 338



36401-05
BRACKET



36405-55
SLUB CATCHER HOLDER




36801-56 / 57
CAM FOLLOWER



36801-92
EXHAUST CHANNEL



36801-97
PULL ROD



36801-109
PULL ROD




36801-116
LEVER



36801-125
LEAF SPRING



36801-155
WORM WHEEL



36801-460
PRISM (ALL SIZES)



37701-38
BEVEL GEAR



37701-43
DRIVE LEVER



37701-92
LID BEARING




37701-104
SWIVEL LID



37710-32 & 33
TOOTHED WHEEL
(Z-32 / Z-48 / Z-14 / Z-56)



37710-131
SENSOR BRACKET



37740-23
TRANSFER ROD



37760-08
CONTROL LEVER



50190-09
CHAIN LINK



52030-01
CAM FOLLOWER



52030-35
UNIVERSAL JOINT



52030-140
LEAF SPRING




52140-06
DRIVE WHEEL



78010-49
FOOT (CADDY BASE)

Schlafhorst Autoconer AC5 & X5




30107 / 1-149008379
LAMP CAP



37720 / 162-149010980
SLIDE PANEL



37720 / 47 – 149000359
MALTESE CROSS



37720 / 192-149000833
LOCKING RING




37720 / 62-149001043
TOOTHED SEGMENT



37720 / 63 & 64 – 149001042
– 149001041 FEEDER ARM



37720 / 27 – 149000369
CHUTE LEVER




37720 / 70-149010310
STRAP



37720 / 160 – 149000899
COUPLING ROD



37720 / 153-149000580
OPENER ARM



30107 / 5-149008381
CAP



37720 / 16-149004560
DRIVE SHAFT GEAR ONLY
(TOP & BOTTOM)



37756 / 7-149000933
COVER



37720 / 124-149011303
SLIDE CURVE LEVER



36802 / 36-149010646
LID LEVER



37720 / 120 & 109
149006239-149006238
CAM DISC



37720 / 41-149001044
FEEDER ARM



37720 / 20-149012385
CAM FOLLOWER



37720 / 137 & 138
149010236-149010234
CREEL ADAPTOR



30132 / 38
GEAR



37720 / 49-149004535
INDEXING PLATE



37720 / 37-149004551
DRIVE PINION



36301 / 1-149008440
COMPONENT CARRIER



37720 / 171-149004182
CENTERING DOOR BRACKET



Schlafhorst Autoconer AC5 & X5




149005382-30107 / 4
SEALING CAP



149000557-37720 / 108
CAM DISK



149003152 – 36320 / 21
WAS SHAFT




149001310 – 36320 / 24
THRUST WASHER



149009400 – 37720 / 130
EJECTOR



149003537-36301 / 6
AIR SWITCH




149002658-37720 / 134
HOUSING COVER



149004735-37720 / 179
CENTERING CHUTE



36320
WAXING DEVICE




149000563-37720 / 131
EJECTION PLATE



149001378-36020 / 20
BLOWER NOZZLE



149004517-37720 / 147
CAM FOLLOWER




32535 / 92
CLUTCH RING




149001540 – 30105 / 9
DIFFUSER



149001425-30105 / 2
PUSH BUTTON



149003452-30105 / 4
PUSH BUTTON



149001429-30105 / 6
INSERT



149003707-30105 / 1
HOUSING



149000556-37720 / 107
BEVEL GEAR




149000389-37720 / 72
STRAP



149002434-37720 / 148
COUPLING ROD



149005345-30105 / 7
DISPLAY



149002639-36802 / 82
COVER



TENSION DISC


Schlafhorst Autoconer (Electronic Spares)



16160-0122(148)
INFORMATOR TOUCH SCREEN



16161-01(147)
INFORMATOR KEYPAD



16161-01 (147)
INFORMATOR DISPLAY (FRONT)




16161-02 (147)
INFORMATOR DISPLAY (BACK)




17550-160 (146)
INFORMATOR KEYPAD




30105-01
CPL OPERATION SECTION



30106-901
CPL INDICATOR UNIT




30107-13
CIRCUIT BALL



30301-19
SENSOR FOR DRUM SHAFT




31635-14
S 6 SENSOR



31635-41
S 7 & S 8 COMBINE SENSOR




32530-35
SENSOR



34101-35
S 4 SENSOR




34101-35
S 4 SENSOR (MODIFIED)




34101-35
S 4 SENSOR (ROUND CABLE)




34101-37
PILE WHEEL FOR BRAKE RING



36201-41
SENSOR YARM TENSION
WITH PROTECTION COVER



42035-10
ELECTRO MAGNET (24 v)







65230-70
INETIAR (ALL TYPE)



32530-30
PILE WHEEL



PCB Repairing



Murata Mach Coner (Model 7-II , 7-V , 21 – C)



003-41B-009
HANDLE STUD



003-41B-013
BUSH



003-41B-013
CRADLE BUSH



003-41B-034
LEVER



003-42A-011
NEEDLE BEARING



003-42A-019
BUNCH GUIDE



003-42A-032
BEARING CENTER COMPLETE



003-42A-037
HOLDER




003-42A-038
BRAKE SHOE




003-422-001
SLEEVE




003-601C-003
YARN TRIP




003-601C-004
YARN TRAP HOLDER



008-45B-005
YARN GUIDE LEVER



008-45B-009
MECHANICAL VALVE



008-45B-022
CAM S 2



008-45B-062X
GUIDE FOR S 10 LEVER



008-45B-062X
LEVER S 10



008-45B-064
SHAFT



008-45B-067
S 10 CAM SPICING BLAST



008-45B-081
HOSE ADAPTOR




008-45B-002X
HEAD PUSHING



008-50A-008A
RACHET WHEEL



008-50A-028X
MAGAZINE BRACKET



0008-52A-015
TRAP DOOR (LH)



Murata Mach Coner (Model 7-II , 7-V , 21 – C)



008-528-018
TRAP DOOR (RH)




008-220-008
ROLLER



008-310-22
PLATE




008-330-001
DRUM STAY SHAFT



008-330-007
DRUM BELT



008-330-025X
BRAKE LEVER



008-330-028X
BRAKE SHOE (OLD)



008-330-028X
BRAKE SHOE (NEW)



008-330-033X
DRUM SHAFT




008-330-036
DRUM COVER



008-331-006X
DRUM PULLEY COMPLETE



008-350-007X
SUCTION DUCT



008-350-010
COMB



008-360-002X
GRIPPER ARM COMPLETE



008-360-008
COVER CLAMP



008-360-034
YARN GUIDE



008-370-005
FIXED CUTTER



008-370-006
MOVABLE CUTTER



008-370-016X
SHUTTER CASE




008-380-003X
GEAR (RETIE PIPE SEGMENT)



008-380-013X
LEVER – A13 (MEMORY CAM)



008-380-021
REVERSING ROLL CAM



008-380-024
MEMORY CAM



008-380-026
DRUM START CAM

Murata Mach Coner (Model 7-II , 7-V , 21 – C)



008-380-038X
GEAR (MOUTH SEGMENT)




008-390-003
MO - GEAR (DRIVE)



008-390-004X
CAM CLUTCH



008-410-058
BUNCH GUIDE



008-480-006
NOZZLE PIPE (8MM)



008-480-006
NOZZLE PIPE (ALL SIZE)



008-480-012
LEVER



008-480-013
LEVER




008-480-022
LEVER (STOPPER)



008-480-026X
LEVER INTERMEDIATE



008-480-045
CLAMP SPACER



008-480-062
AIR GUIDE




008-480-081
CUTTER (FIXED)



008-480-082
CUTTER (MOVABLE)



008-480-089X
PLATE (FRONT)




008-480-094
YARN GUIDE FOR NOZZLE SPINDLE



008-502-006X
HOUSING GEAR



008-502-013X
GEAR SEGMENT



008-530-013X
BOBBIN EJECTOR



008-552-002
PULL BUTTON WITH SINGLE PIECE



008-533-004
WHEEL RACHET



008-553-047 / 048
ARM FILLER




008-570-005
DRIVE GEAR (KO)



008-570-006X
CAM CLUTCH



Murata Mach Coner (Model 7-II , 7-V , 21 - C)



008-570-013
REVERSABLE ROLL



008-601-006
YARN TRAP PACKING



008-602-016
TENSER DISC




008-602-017
TENSER DISC



008-603-007
CUTTER (MOVABLE)



008-603-008
CUTTER (FIXED)



008-603A-037
YARN GUIDE TENSER



008-604-004X
WAX PUSH LEVER



008-604-008
WAXING SHAFT



008-604-026
YARN GUIDE




008-604-029
WAXING BRACKET




008-604-044
SPUR GEAR



008-604-045
YARN GUIDE



008-E30-018
SENSOR



21A-200-034
BRUSH



21A-350-001
DRUM



21A-377-001
BLOCK



21A-380-014
COVER



21A-390-019
CYLINDER



21A-390-020
PISTON



21A-410-013 / 014
HANDLE WITH KNOB



21A-410-017
HANDLE STUD



21A-411-005
BUSH



21A-420-001
SLEEVE

Murata Mach Coner (Model 7-II , 7-V , 21 - C)



21A-422-001
CPL BEARING CENTER



21A-422-008
BEARING CENTER CAP



21A-422-009
BRAKE SHOE



21A-422-017
HOLDER BEARING CPL



21A-422-100
CPL BEARING CENTER



21A-426-002
BEARING HOUSING



21A-426-100
CPL BEARING CENTER



21A-440-006
SHAFT



21A-440-006
CYLINDER



21A-480-041
LEVER ASSEMBLY




21A-520A-028
BODY



21A-520A-031
CERAMIC GUIDE



21A-540-003
CERAMIC GUIDE




21A-540-004
CERAMIC GUIDE



21A-540-017
CERAMIC GUIDE



21A-540-018
LEVER



21A-540-029
CERAMIC GUIDE



21A-540-030
CERAMIC GUIDE



21A-560-003
SHAFT WAX



21A-560-013
CERAMIC GUIDE



21A-608H-047
PIPE



21A-608H-048
BUSH



21A-627-044
WIRE



BUSH DIFFERENT PART
NUMBER




Savio Autoconer (Espero, Espero L, Orion)



1-48 01679-0 15320.0002.1-0
BRAKE SHOES AS-0020 5



1-49 01447-2 1420.0228.6
CONE HOLDER ADAPTOR



1-49 01447-2 1686.0168.2.0 &
161101.0174.0.0 GASKET



1-52 16200.3917.0.0
COMB STRIP



1-52 01444-8 16291.0044.0 / 0
FITTING AS - 0181-18



1-52 01444-8 5426.0081.0.0
COVER CPL AS 0470



1-54 01503-4 16406.0110
DRAGGING UNIT



1-54 01503-4 16846.0113.0.0 &
16856.0377.0.0 COVER & SHOE



1-57 01600-3
16910.0929.0.0 SPRING



1-58 01653-0
16020.1030.0-0 3 LEVER




1-58 01653-0
16140.3448.0.0 PEG



1-117 AS-0421-15
CUTTER




1-121 AS - 0460
SUPPORT CPL GROUP



1-126 15201.002.1.0
YARN TENSIONER



1-126 AS-0241 98
BUSH CPL GROUP



1-132 AS 0181-8
DISC



1-142 00613-1
16526.0079.0.0 GEAR




1-145 AS-0600-5
CAM



1-147 AS-0581 15
PULLEY




1-153 AV-0080 5
CAM



1-153 AV-0080-13
GEAR




17907-0749-1.0-00
CLUTCH



CHAMBERS




FRICTION ROLLER



104-1 DUO BELT
PULLEY CPL



105-3
COUPLING



106-1 S-Z
SHAFT CPL



106-5 S-Z
BEARING SMALL



106- S-Z
BEARING MEDIUM



110-2 CHANGER GEAR
BRACKET RH & LH



111-10
RACHET GEAR



111-14
CHANGE GEAR STUD



114-14
STUD



111-15
QUICK LOCKING DEVICE



118-2 CAM CPL WITH ANTI
PATTERNING DEVICE 152 MM



118
FREE WHEEL CPL



118-18
PAWL



120-1
TRAVERSE SLIDE CPL



120-3 & 4
ROLL RIGHT & LEFT



121-1 CHAIN TENSION
DEVICE CPL



301-1 SPINDLE UPPER
PART CPL



301-4 THREAD GUIDE
ONE WAY



301-4 THREAD GUIDE
DUAL WAY



301-4 THREAD GUIDE
DUAL WAY VTS 09



310-5
BRAKE LINING



302-1
SPINDLE LOWER PART




3202-3
BRAKE SHOE BACKALITE



302-3
BRAKE SHOE STEEL



Star Volkmann TFO



313-4 & 5
SUPPORT RH. MIDDLE. LH



314-5
SUPPORT



314-10
SUPPORT



315-1 PRE TAKE-UP
ROLLER CPL




315-1 PRE TAKE UP
ROLLER CPL CREAMING



316-1 INTERMEDIATE
SUPPORT



317-8 TRAVERSE THREAD
GUIDE WITH SUPPORT CPL



317-16
TRAVERSE COUPLING



303-20 BALL CAGE
WITH INNER RACE




318-2 BALL BEARING
WITH SLEEVE



318-4
FRICTION DRUM 6 INCH



318-4 FRICTION ROLLER
WITH APPRON VTS 06S




319A-1 CONSOLE
ASSEMBLY CPL VTS 07



319A-2 REST FEEDER SPRING
FOR CONSOLE




319-7 & 15
LAGER & KUFE



319A-18 DRUCK
FEEDER SPRING



320-1 CRADLE CPL
FOR VTS 06S



320A-1 CRADLE CPL
FOR VTS 07




320-16 CENTERING DISC
(MULTI PURPOSE)




341-1 INSTANT LUBRIVIST
ASSEMBLY



342-15 REFILING PISTON
WITH SCREW CONNECTION



SPRINGS



SUPPORT CPL WITH
WAX DISC



SUPPORT CPL WITH
WAX DISC



174-1 SPINDE UPPER
PART CPL




174-09
BRAKE SHOE



180-24
VOLCOJET



184-01
OILING DEVICE CPL



188-01 YARN STOP
MOTION CPL



209-06 VARIATOR
ASSEMBLY CPL



209-09
INTERMEDIATE PIECE



209-17
PISTON ASSEMBLY CPL




246-05 ADJUSTABLE BELT
GUIDE ROLLER



246-17
BELT GUIDE ROLLER




253-32 PRE TAKE
UP ROLLER



254-01
COUPLE CPL



254-46
NOZZLE



256-15 CENTERING
DISC MULTI PURPOSE



260-21
DEFLECTION ROLL



266-31 & 266-32
LEVER & HOUSING



359-09 PACKAGE
SUPPORT CPL



359-09 PACKAGE
SUPPORT CPL



359-12 BALL CARE
WITH INNER RACE




360-16
TENSION CAPSULE



360-01
M.T.DEVICE CPL



FREE WHEEL COUPLING



SLEEVE & BRAKE SHOE



V CLAMP



Prerna Leewha TFO



164-1415
COUPLING CPL



164-1431 S-Z GEAR SHAFT
CP WITH BEARING




164-1506
TRAVERSE CAM



164-1520
CAM ROLLER PIN



164-4104
WEIGHT WASHER



164-4106
FLYER



164-4117 & 4118
UPPER & LOWER CAPSULE WITH SPRING



164-4201 SUPPLY
PACKAGE CPL ASSEMBLY



164-4201
SUPPLY PACKAGE



164-4201A
SPINDLE CPL HZ 33-35



164-4207
TENSOR SOCKET CPL



164-4603
TENSION ROLLER BRACKET



164-4604
TENSION ROLLER CPL



164-4701
BRAKE ARM




164-4702 BRAKE SHOE
WITH LINER




164-4708
BRAKE ROLLER CPL



164-4708
BRAKE ROLLER



164-4804 UNDER ROLLER
CPL ASSEMBLY WITH BEARING



164-50355A
DRUM WITH FRICTION RING



164-4708
BRAKE ROLLER CPL



164-5113,5116 CONE
HOLDER BEARING TYPE



164-5502 C.T. HOUSING
CPL ASSEMBLY



164-5310
BEARING CAP




164-5407
TRAVERSE YARN GUIDE



164-6128 O.F.ROLLER CPL
WITH ROLLER TYPE DISC



164-6208
GUIDE ROLLER CPL




164-6310
BALLON GUIDE BAR



164-6404
DROPPER BRACKET



164-6408
STOP MOTION SENSOR




164-6417B
DROPPER CPL



164-7205 & 7209
WORM GEAR & WORM



164-7228
CONNECTING ROD ASSEMBLY



164-8115
TAILING ROLLER



164-8310
WAXING ROLLER CPL



560-2211
DRIVING SHAFT




560-1813
TENSION PULLEY



560-1818
TENSION PULLEY SHAFT



560-4705 BRAKE
CONNECTOR CPL ASSEMBLY



560-4711 BRAKE
PEDDEL BUSING



560-4712 BRAKE
PEDAL STOPPER



560-5103
CRADLE BRACKET



560-5103
CRADLE BRACKET




560-5404 TRAVERSE
GUIDE HOLDER CPL



560-6201 GUIDE
ROLLER BRACKET CPL




164-6306 BALLON
GUIDE BAR HOLDER



560-6305 BALLON
GUIDE BAR HOLDER



560-6407
DROPPER BRACKET



560-6408
DROPPER



E-144, Dev Nagar, Dev Nagar Derasar Lane, Near Bhatia school,
Kandivali West, Mumbai - 67. Mob – 7710053144 / 9323404942
Email - info@vimalsales.com / www.vimalsales.com